




## RT 11 AKH – AIR TAPPING TOOL



SL.NO	PART NO	DESCRIPTION	QTY	SL.NO	PART NO	DESCRIPTION	QTY
1	SRT 01-102-03	ROTOR BLADE	6	19	SRT 20-702-01	ROD	2
2	SRT 02-200-07	O RING	1	20	SRT 25-702-12	AIR INLET	1
3	SRT 02-202-03	O RING	1	21	SRT 26-501-02	MUFFLER	1
4	SRT 03-300-02	PLASTIC BALL	2	22	SRT 31-703-01	HOOK	1
5	SRT 03-700-04	STEEL BALL	1	23	SRT 35-406-02	ROTOR	1
6	SRT 04-700-03	PIN	1	24	SRT 36-503-15	FRONT PLATE	1
7	SRT 04-701-04	PIN	1	25	SRT 37-503-02	REAR PLATE	1
8	SRT 04-701-05	PIN	1	26	SRT 38-503-01	CYLINDER	1
9	SRT 04-702-04	PIN	9	27	SRT 48-703-01	GEAR RING	1
10	SRT 09-702-04	STOPPING WHEEL	1	28	SRT 49-502-02	GEAR SEAT	1
11	SRT 13-702-01	SCREW	1	29	SRT 51-402-09	BUSHING	1
12	SRT 15-701-07	BALL BEARING	1	30	SRT 51-701-04	BUSHING	1
13	SRT 15-702-04	BALL BEARING	1	31	SRT 74-707-18	DRIVING ROD	1
14	SRT 15-702-10	BALL BEARING	1	32	SRT 75-704-01	FRONT CAP	1
15	SRT 15-703-01	BALL BEARING	1	33	SRT 75-707-01	FRONT CAP	1
16	SRT 16-701-02	GEAR	1	34	SRT 78-616-01	HANDLE	1
17	SRT 16-701-08	GEAR	1	35	SRT 79-608-09	HANDLE	1
18	SRT 17-704-01	SWITCH LEVER	1	36	SRT 80-705-05	CHUCK	1

**RAMSIVE TOOLS PVT.LTD.**

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.