


RT 522 – ANGLE GRINDER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 522-01	MOTOR HOUSING	1	20	SRT 522-20	BALL BEARING	2
2	SRT 522-02	LEVER PIN	1	21	SRT 522-21	CONTROLLER	1
3	SRT 522-03	AIR INLET	1	22	SRT 522-22	PINION GEAR	1
4	SRT 522-04	THROTTLE LEVER	1	23	SRT 522-23	FRONT COUPLING	1
5	SRT 522-05	VALVE STEM	1	24	SRT 522-24	COLLET	1
6	SRT 522-06	DEFLECTOR	1	25	SRT 522-25	COLLET NUT	1
7	SRT 522-07	O - RING	1	26	SRT 522-26	FRONT CAP	1
8	SRT 522-08	SPRING	1	27	SRT 522-27	SPANNER	2
9	SRT 522-09	O - RING	1	28	SRT 522-28	HEAD	1
10	SRT 522-10	VALVE SCREW	1	29	SRT 522-29	RETIANER RING	1
11	SRT 522-11	O - RING	1	30	SRT 522-30	BEVEL GEAR	1
12	SRT 522-12	ROTOR SPACER	1	31	SRT 522-31	LOCK SPRING	1
13	SRT 522-13	BALL BEARING	2	32	SRT 522-32	KEY	1
14	SRT 522-14	REAR END PLATE	1	33	SRT 522-33	SPINDLE	1
15	SRT 522-15	ROTOR	1	34	SRT 522-34	BUSHING	1
16	SRT 522-16	VANE	4	35	SRT 522-35	O - RING	1
17	SRT 522-17	SPRING PIN	2	36	SRT 522-36	O - RING	1
18	SRT 522-18	CYLINDER	1	37	SRT 522-37	OIL CAP	1
19	SRT 522-19	FRONT END PLATE	1	38	SRT 522-38	STEEL BALL	1

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.