




RT 1206P – 6” ANGLE POLISHER



SL.NO	PART NO	DESCRIPTION	QTY	SL.N O	PART NO	DESCRIPTION	QTY
1	SRT1206P 01	PLUG	1	25	SRT1206P 25	HOUSING BAND	1
2	SRT1206P 02	AIR INLET	1	26	SRT1206P 26	MOTOR HOUSING	1
3	SRT1206P 03	VALVE BODY	1	27	SRT1206P 27	BEARING	1
4	SRT1206P 04	LEVER	1	28	SRT1206P 28	BEVEL GEAR	1
5	SRT1206P 05	LEVER PIN	1	29	SRT1206P 29	SPINDLE	1
6	SRT1206P 06	VALVE BUSHING	1	30	SRT1206P 30	WOODRUF KEY	1
7	SRT1206P 07	VALVE STEM	1	31	SRT1206P 31	HOUSING CAP	1
8	SRT1206P 08	O RING	1	32	SRT1206P 32	BEARING	1
9	SRT1206P 09	VAVLVE SPRING	1	33	SRT1206P 33	RETAINING RING	1
10	SRT1206P 10	AIR CONTROLLER	1	34	SRT1206P 34	HANDLE	1
11	SRT1206P 11	O RING	1	35	SRT1206P 35	WASHER SPRING	1
12	SRT1206P 12	VALVE SCREW	1	36	SRT1206P 36	CAP SCREW	4
13	SRT1206P 13	GASKET	1	37	SRT1206P 37	BEARING PLATE	1
14	SRT1206P 14	REATAINING RING	1	38	SRT1206P 38	EXHAUST DEFLECTOR	1
15	SRT1206P 15	BEARING	1	39	SRT1206P 39	EXHAUST DEFLECTOR SCREW	1
16	SRT1206P 16	REA END PLATE	1	40	SRT1206P 40	REATAINING RING	2
17	SRT1206P 17	ROTOR BLADE	4	41	SRT1206P 41	WAVE WASHER	1
18	SRT1206P 18	ROTOR	1	42	SRT1206P 42	SPRING WASHER	1
19	SRT1206P 19	CYLINDER PIN	1	43	SRT1206P 43	SCREW	4
20	SRT1206P 20	CYLINDER	1	44	SRT1206P 44	WAVE WASHER	4
21	SRT1206P 21	FRONT END PLATE	1	45	SRT1206P 45	O RING	1
22	SRT1206P 22	BEARING	1	46	SRT1206P 46	LOCK NUT	1
23	SRT1206P 23	BEARING	1	47	SRT1206P 47	7"SANDING PAD	1
24	SRT1206P 24	PINION	1				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.