




## RT 1206S – ANGLE SANDER / POLISHER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 1206S-02	AIR INLET	1	24	SRT 1206S-25	HOUSING BAND	1
2	SRT 1206S-03	VALVE BODY	1	25	SRT 1206S-26	MOTOR HOUSING	1
3	SRT 1206S-04	LEVER	1	26	SRT 1206S-27	BEARING	1
4	SRT 1206S-05	LEVER PIN	1	27	SRT 1206S-28	BEVEL GEAR	1
5	SRT 1206S-06	VALVE BUSHING	1	28	SRT 1206S-29	SPINDLE	1
6	SRT 1206S-07	VALVE STEM	1	29	SRT 1206S-30	WOODRUF KEY	1
7	SRT 1206S-08	O RING	1	30	SRT 1206S-31	HOUSING CAP	1
8	SRT 1206S-09	VAVLVE SPRING	1	31	SRT 1206S-32	BEARING	1
9	SRT 1206S-10	AIR CONTROLLER	1	32	SRT 1206S-33	RETAINING RING	1
10	SRT 1206S-11	O RING	1	33	SRT 1206S-35	HANDLE	1
11	SRT 1206S-12	VALVE SCREW	1	34	SRT 1206S-39	EXHAUST DEFLECTOR	1
12	SRT 1206S-13	GASKET	1	35	SRT 1206S-40	EXHAUST DEFLECTOR SCREW	1
13	SRT 1206S-14	RETAINING RING	1	36	SRT 1206S-41	RETAINING RING	2
14	SRT 1206S-15	BEARING	1	37	SRT 1206S-42	WAVE WASHER	1
15	SRT 1206S-16	REA END PLATE	1	38	SRT 1206S-43	SPRING WASHER	1
16	SRT 1206S-17	ROTOR BLADE	4	39	SRT 1206S-44	SCREW	4
17	SRT 1206S-18	ROTOR	1	40	SRT 1206S-45	WAVE WASHER	4
18	SRT 1206S-19	CYLINDER PIN	1	41	SRT 1206S-46	O RING	1
19	SRT 1206S-20	CYLINDER	1	42	SRT 1206S-47	LOCK NUT	1
20	SRT 1206S-21	FRONT END PLATE	1	43	SRT 1206S-48	7" SANDING PAD	1
21	SRT 1206S-22	BEARING	1	44	SRT 1206S-49	STOP WRENCH	1
22	SRT 1206S-23	BEARING	1	45	SRT 1206S-50	DISC WRENCH	1
23	SRT 1206S-24	PINION	1				

**RAMSIVE TOOLS PVT.LTD.**

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.