




## RT 1387 AN5 – PALM SANDER



| SI.NO | PART NO                    | DESCRIPTION          | QTY | SI.NO | PART NO        | DESCRIPTION              | QTY |
|-------|----------------------------|----------------------|-----|-------|----------------|--------------------------|-----|
| 1     | SRT 1387AN5-01             | HOUSING ASSEMBLY     | 1   | 27    | SRT 1387AN5-27 | SPRING                   | 1   |
| 2     | SRT 1387AN5-02             | BLOCK                | 1   | 28    | SRT 1387AN5-28 | SCREW                    | 2   |
| 3     | SRT 1387AN5-03             | SCREW                | 2   | 29    | SRT 1387AN5-29 | SPRING PIN               | 1   |
| 4     | SRT 1387AN5-04             | DISK RELEASE BUTTON  | 1   | 30    | SRT 1387AN5-30 | AIR ADJUSTMENT SHAFT     | 1   |
| 5     | SRT 1387AN5-05             | THROTTLE LEVER PIN   | 1   | 31    | SRT 1387AN5-31 | O - RING                 | 1   |
| 6     | SRT 1387AN5-06             | RETAINER RING        | 1   | 32    | SRT 1387AN5-32 | SHAFFT BUSHING           | 1   |
| 7*    | SRT 1387AN5-07             | BALL BEARING         | 1   | 33    | SRT 1387AN5-33 | O - RING                 | 1   |
| 8     | SRT 1387AN5-08             | CYLINDER UPPER COVER | 1   | 34    | SRT 1387AN5-34 | THROTTLE LEVER           | 1   |
| 9     | SRT 1387AN5-09             | CYLINDER             | 1   | 35    | SRT 1387AN5-35 | SPRING PIN               | 1   |
| 10    | SRT 1387AN5-10             | WASHER               | 1   | 36    | SRT 1387AN5-36 | WASHER                   | 1   |
| 11    | SRT 1387AN5-11             | ROTOR                | 1   | 37    | SRT 1387AN5-37 | OUTLET BUSHING           | 1   |
| 12*   | SRT 1387AN5-12             | ROTOR BLADE          | 5   | 38    | SRT 1387AN5-38 | MUFFLER CUP              | 1   |
| 13    | SRT 1387AN5-13             | CYLINDER LOWER COVER | 1   | 39    | SRT 1387AN5-39 | SAFETY BUCKLE            | 1   |
| 14*   | SRT 1387AN5-14             | BALL BEARING         | 1   | 40*   | SRT 1387AN5-40 | PU WASHER                | 1   |
| 15    | SRT 1387AN5-15             | SPRING PIN           | 1   | 41    | SRT 1387AN5-41 | AIR INLET SHAFT          | 1   |
| 16    | SRT 1387AN5-16             | O - RING             | 1   | 42    | SRT 1387AN5-42 | VALVE SPRING             | 1   |
| 17    | SRT 1387AN5-17             | LOCK NUT             | 1   | 43    | SRT 1387AN5-43 | O - RING                 | 2   |
| 18    | SRT 1387AN5-18             | KEY                  | 1   | 44    | SRT 1387AN5-44 | AIR INLET                | 1   |
| 19    | SRT 1387AN5-19             | SPINDLE              | 1   | 45    | SRT 1387AN5-45 | EXHAUST ADJUSTMENT SHAFT | 1   |
| 20    | SRT 1387AN5-20             | BALANCER             | 3   | 46    | SRT 1387AN5-46 | O - RING                 | 2   |
| 21*   | SRT 1387AN5-21             | BALL BEARING         | 1   | 47    | SRT 1387AN5-47 | EXHAUST DEFLECTOR        | 1   |
| 22    | SRT 1387AN5-22             | BEARING SEAL         | 1   | 48    | SRT 1387AN5-48 | TUBE CONNECTOR           | 1   |
| 23    | SRT 1387AN5-23             | WASHER               | 1   | 49    | SRT 1387AN5-49 | DUST PROTECTION COVER    | 1   |
| 24    | SRT 1387AN5-24             | BALANCER SHAFT       | 1   | 50    | SRT 1387AN5-50 | DUST PROTECTION RING     | 1   |
| 25    | SRT 1387AN5-25             | RETAINER RING        | 1   | 51    | SRT 1387AN5-51 | SCREW                    | 5   |
| 26    | SRT 1387AN5-26             | DISK RELEASE STOPPER | 1   | 52    | SRT 1387AN5-52 | PAD 5"                   | 1   |
|       | * Are Easily Damaged Parts |                      |     |       |                |                          |     |

**RAMSIVE TOOLS PVT.LTD.**

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.