




RT 1387AN6 – PALM SANDER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 1387AN6-01	HOUSING ASSEMBLY	1	27	SRT 1387AN6-27	SPRING	1
2	SRT 1387AN6-02	BLOCK	1	28	SRT 1387AN6-28	SCREW	2
3	SRT 1387AN6-03	SCREW	2	29	SRT 1387AN6-29	SPRING PIN	1
4	SRT 1387AN6-04	DISK RELEASE BUTTON	1	30	SRT 1387AN6-30	AIR ADJUSTMENT SHAFT	1
5	SRT 1387AN6-05	THROTTLE LEVER PIN	1	31	SRT 1387AN6-31	O - RING	1
6	SRT 1387AN6-06	RETAINER RING	1	32	SRT 1387AN6-32	SHAFFT BUSHING	1
7*	SRT 1387AN6-07	BALL BEARING	1	33	SRT 1387AN6-33	O - RING	1
8	SRT 1387AN6-08	CYLINDER UPPER COVER	1	34	SRT 1387AN6-34	THROTTLE LEVER	1
9	SRT 1387AN6-09	CYLINDER	1	35	SRT 1387AN6-35	SPRING PIN	1
10	SRT 1387AN6-10	WASHER	1	36	SRT 1387AN6-36	WASHER	1
11	SRT 1387AN6-11	ROTOR	1	37	SRT 1387AN6-37	OUTLET BUSHING	1
12*	SRT 1387AN6-12	ROTOR BLADE	5	38	SRT 1387AN6-38	MUFFLER CUP	1
13	SRT 1387AN6-13	CYLINDER LOWER COVER	1	39	SRT 1387AN6-39	SAFETY BUCKLE	1
14*	SRT 1387AN6-14	BALL BEARING	1	40*	SRT 1387AN6-40	PU WASHER	1
15	SRT 1387AN6-15	SPRING PIN	1	41	SRT 1387AN6-41	AIR INLET SHAFT	1
16	SRT 1387AN6-16	O - RING	1	42	SRT 1387AN6-42	VALVE SPRING	1
17	SRT 1387AN6-17	LOCK NUT	1	43	SRT 1387AN6-43	O - RING	2
18	SRT 1387AN6-18	KEY	1	44	SRT 1387AN6-44	AIR INLET	1
19	SRT 1387AN6-19	SPINDLE	1	45	SRT 1387AN6-45	EXHAUST ADJUSTMENT SHAFT	1
20	SRT 1387AN6-20	BALANCER	3	46	SRT 1387AN6-46	O - RING	2
21*	SRT 1387AN6-21	BALL BEARING	1	47	SRT 1387AN6-47	EXHAUST DEFLECTOR	1
22	SRT 1387AN6-22	BEARING SEAL	1	48	SRT 1387AN6-48	TUBE CONNECTOR	1
23	SRT 1387AN6-23	WASHER	1	49	SRT 1387AN6-49	DUST PROTECTION COVER	1
24	SRT 1387AN6-24	BALANCER SHAFT	1	50	SRT 1387AN6-50	DUST PROTECTION RING	1
25	SRT 1387AN6-25	RETAINER RING	1	51	SRT 1387AN6-51	SCREW	5
26	SRT 1387AN6-26	DISK RELEASE STOPPER	1	52	SRT 1387AN6-52	PAD 6"	1
* Are Easily Damaged Parts							

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.