




RT 2035TL – IMPACT WRENCH



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 2035TL-01	FRONT RUBBER	1	29	SRT 2035TL-30	BALL BEARING	1
2	SRT 2035TL-02	HANDLE	1	30	SRT 2035TL-31	REAR GASKET	1
3	SRT 2035TL-03	CLAMPER	1	31	SRT 2035TL-32	HANDLE FRAME	1
4	SRT 2035TL-04	HEX.WRENCH	1	32	SRT 2035TL-33	CAP SCREW	4
5	SRT 2035TL-05	CAP SCREW	2	33	SRT 2035TL-34	SPRING PIN	1
6	SRT 2035TL-06	OIL SEAL	1	34	SRT 2035TL-35	PIN	1
7	SRT 2035TL-07	HAMMER CASE	1	35	SRT 2035TL-36	OUTER TRIGGER	1
8	SRT 2035TL-08	CAP SCREW	4	36		INNER TRIGGER	1
9	SRT 2035TL-09	SPRING WASHER	8	37	SRT 2035TL-37	REVERSE VALVE BUSHING	1
10	SRT 2035TL-10	ANVIL BUSHING	1	38	SRT 2035TL-38	REGULATOR	1
11	SRT 2035TL-12	O - RING	1	39	SRT 2035TL-39	STEEL BALL	1
12	SRT 2035TL-13	ANVIL COLLER	1	40	SRT 2035TL-40	SPRING	1
13	SRT 2035TL-14G	ANVIL	1	41	SRT 2035TL-41	SPRING PIN	1
14	SRT 2035TL-15G	HAMMER	2	42	SRT 2035TL-42	SPRING PIN	1
15	SRT 2035TL-16	HAMMER PIN	2	43	SRT 2035TL-43	O - RING	1
16	SRT 2035TL-17	HAMMER CAGE	1	44	SRT 2035TL-44	OIL CHAMBER SCREW	1
17	SRT 2035TL-18	REAR WASHER	1	45	SRT 2035TL-45	VALVE BUSHING	1
18	SRT 2035TL-19	FRONT GASKET	1	46	SRT 2035TL-46	BUSHING	1
19	SRT 2035TL-20	MOTOR HOUSING	1	47	SRT 2035TL-47	VALVE STEM	1
20	SRT 2035TL-21	LOCK NUT	10	48	SRT 2035TL-48	STEEL BALL	1
21	SRT 2035TL-22	BALL BEARING	1	49	SRT 2035TL-49	SPRING	1
22	SRT 2035TL-23	FRONT END PLATE	1	50	SRT 2035TL-50	O - RING	1
23	SRT 2035TL-24	ROTOR	1	51	SRT 2035TL-51	AIR INLET	1
24	SRT 2035TL-25	ROTOR BLADE	6	52	SRT 2035TL-52	HOUSING BAND	1
25	SRT 2035TL-26	SPRING PIN	2	53	SRT 2035TL-54	RUBBER PROTECTOR	1
26	SRT 2035TL-27	CYLINDER	1	54	SRT 2035TL-55	O - RING	2
27	SRT 2035TL-28	SPRING PIN	1	55	SRT 2035TL-56	STOPPER	1
28	SRT 2035TL-29	REAR END PLATE	1	56	SRT 2035TL-57	GASKET	1

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.