




## RT 47-4072L8 - 1" IMPACT WRENCH



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 47-4072L8 -01	MOTOR HOUSING	1	23	SRT 47-4072L8 -23	SPRING	1
2	SRT 47-4072L8 -02	PIN	1	24	SRT 47-4072L8 -24	PIN	1
3	SRT 47-4072L8 -03	AIR INLET	1	25	SRT 47-4072L8 -25	ANVIL BUSHING	1
4	SRT 47-4072L8 -04	TRIGGER	1	26	SRT 47-4072L8 -27	SPRING PIN	1
5	SRT 47-4072L8 -05	VALVE STEM	1	27	SRT 47-4072L8 -28	HAMMER CASE	1
6	SRT 47-4072L8 -06	REVERSE VALVE BUSHING	1	28	SRT 47-4072L8 -29	GASKET	1
7	SRT 47-4072L8 -07	O - RING	1	29	SRT 47-4072L8 -30	SCREW	8
8	SRT 47-4072L8 -08	VALVE SPRING	1	30	SRT 47-4072L8 -32	BALL BEARING	1
9	SRT 47-4072L8 -09	O - RING	1	31	SRT 47-4072L8 -33	HAMMER CAGE	1
10	SRT 47-4072L8 -10	SPRING PIN	2	32	SRT 47-4072L8 -34	HAMMER	2
11	SRT 47-4072L8 -11	GASKET	1	33	SRT 47-4072L8 -35	HAMMER PIN	2
12	SRT 47-4072L8 -12	REAR COVER	1	34	SRT 47-4072L8 -36	ANVIL 1"	1
13	SRT 47-4072L8 -13	BALL BEARING	1	35	SRT 47-4072L8 -36	ANVIL 6"	1
14	SRT 47-4072L8 -14	REAR END PLATE	1	36	SRT 47-4072L8 -36	ANVIL 8"	1
15	SRT 47-4072L8 -15	ROTOR	1	37	SRT 47-4072L8 -37	O - RING	1
16	SRT 47-4072L8 -16	ROTOR BLADE	1	38	SRT 47-4072L8 -38	RETAINER RING	1
17	SRT 47-4072L8 -17	SPRING PIN	2	39	SRT 47-4072L8 -39	SPRING PIN	1
18	SRT 47-4072L8 -18	CYLINDER	1	40	SRT 47-4072L8 -40	DEAD HANDLE	1
19	SRT 47-4072L8 -19	FRONT END PLATE	1	41	SRT 47-4072L8 -41	SCREW	4
20	SRT 47-4072L8 -20	BALL BEARING	1	42	SRT 47-4072L8 -43	HEX.KEY WRENCH	1
21	SRT 47-4072L8 -21	AIR REGULATOR	1	43	SRT 47-4072L8 -46	VALVE BUSHING	1
22	SRT 47-4072L8 -22	O - RING	1				

**RAMSIVE TOOLS PVT.LTD.**

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.