




RT 47-4075 - IMPACT WRENCH



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 47-4075-01	MOTOR HOUSING	1	26	SRT 47-4075-26	SPRING PIN	1
2	SRT 47-4075-02	SPRING PIN	1	27	SRT 47-4075-27	SPRING PIN	1
3	SRT 47-4075-03	AIR INLET	1	28	SRT 47-4075-28	HAMMER CASE	1
4	SRT 47-4075-04	TRIGGER	1	29	SRT 47-4075-29	GASKET	1
5	SRT 47-4075-05	O - RING	1	30	SRT 47-4075-30	SCREW	8
6	SRT 47-4075-06	REVERSE VALVE BUSHING	1	31	SRT 47-4075-32	BALL BEARING	1
7	SRT 47-4075-07	EXHAUST DIFEUSER	1	32	SRT 47-4075-33	HAMMER CAGE	1
8	SRT 47-4075-08	O - RING	1	33	SRT 47-4075-34	HAMMER	2
9	SRT 47-4075-09	O - RING	1	34	SRT 47-4075-35	HAMMER PIN	2
10	SRT 47-4075-10	REVERSE VALVE	1	35	SRT 47-4075-36	ANVIL - 1"	1
11	SRT 47-4075-11	GASKET	1			ANVIL - 6"	1
12	SRT 47-4075-12	REAR COVER	1			ANVIL - 8"	1
13	SRT 47-4075-13	BALL BEARING	1	36	SRT 47-4075-37	O - RING	1
14	SRT 47-4075-14	REAR AND PLATE	1	37	SRT 47-4075-38	RETAINER RING	1
15	SRT 47-4075-15	ROTOR	1	38	SRT 47-4075-39	SPRING PIN	2
16	SRT 47-4075-16	ROTOR BLADE	6	39	SRT 47-4075-40	DEAD HANDLE	1
17	SRT 47-4075-17	SPRING PIN	2	40	SRT 47-4075-41	SCREW	4
18	SRT 47-4075-18	CYLINDER	1	41	SRT 47-4075-42	VALVE SPRING	1
19	SRT 47-4075-19	FRONT END PLATE	1	42	SRT 47-4075-43	VALVE STEM	1
20	SRT 47-4075-20	BALL BEARING	1	43	SRT 47-4075-44	RUBBER SPACER	1
21	SRT 47-4075-21	REVERSE LEVER	1	44	SRT 47-4075-45	O - RING	1
22	SRT 47-4075-22	O - RING	1	45	SRT 47-4075-46	VALVE BUSHING	1
23	SRT 47-4075-23	SPRING PIN	1	46	SRT 47-4075-48	HEX.KEY WRENCH	1
24	SRT 47-4075-24	STEEL BALL	1	47	SRT 47-4075-49	RUBBER GRIP	1
25	SRT 47-4075-25	ANIL BUSHING	1				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.