




RT 501 – AUTO SHUT OFF SCREW DRIVER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 501-01	HANGER	1	28	SRT 501-28	BEARING SPACER	1
2	SRT 501-02	INLET BUSH	1	29	SRT 501-29	CLUTCH	1
4	SRT 501-04	SPILLING	1	29-1	SRT 501-29-1	SPINDLE(FRONT)	1
5	SRT 501-05	VALVE BALL	1	30	SRT 501-30	CAM CLUTCH BALL	1
6	SRT 501-06	O RING	1	31	SRT 501-31	BALL SHEET	1
7	SRT 501-07	BLOW COVER	1	32	SRT 501-32	GEAR CASE	1
7-1	SRT 501-07-1	EXHAUST REFLCTOTR	1	33	SRT 501-33	SPRING	1
8	SRT 501-08	THROTTLE BUSH BAR	1	34	SRT 501-34	SPRING RECEIVER	1
9	SRT 501-09	FRAME	1	35	SRT 501-35	CAM RIDER	1
10	SRT 501-10	CHANGE VALVE BUSH	1	36	SRT 501-36	PILOT SHAFT	1
11	SRT 501-11	CHANGE VALVE SPRING	1	36-1	SRT 501-36-1	SPILING	1
12	SRT 501-12	CHANGE VALVE	1	37	SRT 501-37	SPILING	1
13	SRT 501-13	PIN	1	38	SRT 501-38	SPILING	1
14	SRT 501-14	BEARING	1	39	SRT 501-39	SPINDLR(FRONT)	1
15	SRT 501-15	PIN	1	40	SRT 501-40	CAMRIDER BALL	2
16	SRT 501-16	END PLATE(BACK)	1	41	SRT 501-41	CAMRIDER BALL	2
17	SRT 501-17	CYLINDER	1	42	SRT 501-42	SPRING RECEIVER	1
18	SRT 501-18	ROTOR	1	43	SRT 501-43	CLUTCH COVER	1
19	SRT 501-19	ROTOR BLADE	4	44	SRT 501-44	PIN	4
20	SRT 501-20	END PLATE(FRONT)	1	45	SRT 501-45	ADJUST DIAL	1
21	SRT 501-21	BEARING	1	46	SRT 501-46	C-PIN	1
23	SRT 501-23	INTERNAL GEAR	1	47	SRT 501-47	WASHER	1
24	SRT 501-24	FREE GEAR	8	48	SRT 501-48	SPRING	1
25	SRT 501-25	GEAR FRAME(BACK)	1	49	SRT 501-49	PIT STOPPER	1
26	SRT 501-26	GEAR FRAME(FRONT)	1	50	SRT 501-50	C-PIN	1
27	SRT 501-27	BEARING	2				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.