




RT 5021 – 1/4 ” SCREW DRIVER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 5021-01	RETAINING RING	3	28	SRT 5021-28	PIN	1
2	SRT 5021-02	WASHER	1	29	SRT 5021-29	ROTOR BLADE	5
3	SRT 5021-03	SPRING	1	30	SRT 5021-30	ROTOR	1
4	SRT 5021-04	BALL RETAINER	1	31	SRT 5021-31	CYLINDER	1
5	SRT 5021-05	CLUTCH HOUSING	1	32	SRT 5021-32	END PLATE	1
6	SRT 5021-06	SPACER	1	33	SRT 5021-33	CYLINDER WASHER	1
7	SRT 5021-07	ADJUST NUT	1	34	SRT 5021-34	HOUSING	1
8	SRT 5021-08	WASHER	1	35	SRT 5021-35	PIN	1
9	SRT 5021-09	SPRING	1	36	SRT 5021-36	TRIGGER	1
10	SRT 5021-10	WASHER	1	37	SRT 5021-37	SPRING	1
11	SRT 5021-11	STEEL BALL	4	38	SRT 5021-38	O - RING	1
12	SRT 5021-12	CLUTCH CARRIER	1	39	SRT 5021-39	REVERSE VALVE	1
13	SRT 5021-13	STEEL BALL	1	40	SRT 5021-40	O - RING	1
14	SRT 5021-14	CAM SPINDLE	1	41	SRT 5021-41	REVERSE VALVE BUSH	1
15	SRT 5021-15	INTERNAL STOP RING	1	42	SRT 5021-42	O - RING	1
16	SRT 5021-16	DRIVE DOG	1	43	SRT 5021-43	THROTTLE VALVE	1
17	SRT 5021-17	RING	1	44	SRT 5021-44	O - RING	1
18	SRT 5021-18	CLAMP NUT	1	45	SRT 5021-45	MUFFLER	1
19	SRT 5021-19	BALL BEARING	1	46	SRT 5021-46	TAPING SCREW	1
20	SRT 5021-20	INTERNAL GEAR	1	47	SRT 5021-47	AIR INLET	1
21	SRT 5021-21	SPRING GUIDE	1	48	SRT 5021-48	WAVE WASHER	1
22	SRT 5021-22	CONE SPRING	1	49	SRT 5021-49	EXHAUST DIFFUSER	1
23	SRT 5021-23	WORK SPINDLE	1	50	SRT 5021-50	O - RING	1
24	SRT 5021-24	NEEDLE ROLLER	3	51	SRT 5021-51	PIN	1
25	SRT 5021-25	PLANET GEAR	3	52	SRT 5021-52	COVER	1
26	SRT 5021-26	BEARING	2	53	SRT 5021-53	WRENCH	1
27	SRT 5021-27	FRONT PLATE	1	54	SRT 5021-54	HEXAGON WRENCH KEY	1

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.