




RT 504 - IMPACT SCREW DRIVER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 504-01	HANGER	1	20	SRT 504-20	CYLINDER	1	39	SRT 504-39	PIN	4
2	SRT 504-02	INLET BUSH	1	21	SRT 504-21	ROTOR PROFELLER	5	40	SRT 504-40	ADJUST DIAL	1
3	SRT 504-03	BLOW COVER	1	22	SRT 504-22	ROTOR	1	41	SRT 504-41	SCREW	6
4	SRT 504-04	EXHAUST REFLECTOR	1	23	SRT 504-23	END PLATE(FRONT)	1	42	SRT 504-42	FIX SCREW	1
5	SRT 504-05	LEVER	1	24	SRT 504-24	BEARING	1	43	SRT 504-43	BEARING	1
6	SRT 504-06	PIN	1	25	SRT 504-25	INTERNAL GEAR	1	44	SRT 504-44	FIX COVER	1
7	SRT 504-07	PIN	1	26	SRT 504-26	GEAR CASE	1	45	SRT 504-45	NUT	1
8	SRT 504-08	VALVE BODY	1	27	SRT 504-27	FREE GEAR	8	46	SRT 504-46	FIX SCREW	1
9	SRT 504-09	INLET WASHER	3	28	SRT 504-28	GEAR FRAME	1	47	SRT 504-47	BEARING	1
10	SRT 504-10	O-RING	1	29	RS504-29	FREE GEAR	1	48	SRT 504-48	BEVEL	1
11	SRT 504-11	VALVE	1	30	SRT 504-30	BEARING	2	49	SRT 504-49	ANGLE HOUSING	1
12	SRT 504-12	SPILING	1	31	SRT 504-31	BEARING SPACER	1	50	SRT 504-50	BEARING	1
13	SRT 504-13	FRAME	1	32	SRT 504-32	CLUTCH	1	51	SRT 504-51	BEARING	1
14	SRT 504-14	O-RING	1	33	SRT 504-33	CAM CLUTCH BALL	2	52	SRT 504-52	GEARED SPINDLE	1
15	SRT 504-15	REVERSE VALVE	1	34	SRT 504-34	BALL SEAT	1	53	SRT 504-53	O-RING	1
16	SRT 504-16	PIN	1	35	SRT 504-35	SPILING	1	54	SRT 504-54	BALL	1
17	SRT 504-17	PIN	1	36	SRT 504-36	SPILING(FRONT)	1	55	SRT 504-55	ROTOR BALL	9
18	SRT 504-18	BALL BEARING	1	37	SRT 504-37	SPILING RECEIVER	1	56	SRT 504-56	LOCK RING	1
19	SRT 504-19	END PLATE(BACK)	1	38	SRT 504-38	CLUTCH COVER	1	57	SRT 504-57	RING	1

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.