




RT 827 LS – RATCHET WRENCH



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 01-104-06	ROTOR BLADE	6	19	SRT 15-702-04	BALL BEARING	1	37	SRT 43-703-08	HAMMER CAM	1
2	SRT 02-200-04	O - RING	1	20	SRT 15-702-09	BALL BEARING	1	38	SRT 48-703-16	GEAR RING	1
3	SRT 02-200-07	O - RING	1	21	SRT 15-702-10	BALL BEARING	1	39	SRT 49-702-13	GEAR SEAT	1
4	SRT 02-203-02	O - RING	1	22	SRT 15-703-02	BALL BEARING	1	40	SRT 51-702-26	BUSHING	1
5	SRT 04-700-03	PIN	1	23	SRT 15-703-07	BALL BEARING	1	41	SRT 52-702-20	WASHER	1
6	SRT 04-701-07	PIN	1	24	SRT 15-703-08	BALL BEARING	1	42	SRT 52-704-09	WASHER	1
7	SRT 04-701-14	PIN	3	25	SRT 16-701-11	GEAR	3	43	SRT 57-711-01	ROD	1
8	SRT 04-702-02	PIN	1	26	SRT 17-704-03	SWITCH LEVER	1	44	SRT 57-711-02	ROD	1
9	SRT 04-702-03	PIN	1	27	SRT 21-701-05	CONTROLLER	1	45	SRT 58-712-01	CAM CASE	1
10	SRT 05-702-03	PIN	1	28	SRT 24-702-05	VALVE ROD	1	46	SRT 60-711-01	OPERATING ROD	1
11	SRT 06-701-08	SPRING	2	29	SRT 25-703-03	AIR INLET (FT)	1	47	SRT 61-701-01	CAM SEAT	1
12	SRT 06-703-03	SPRING	1	30	SRT 26-704-02	MUFFLER	1	48	SRT 62-704-27	RATCHET GEAR	1
13	SRT 08-701-03	SPRING	1	31	SRT 35-709-07	ROTOR	1	49	SRT 64-400-01	OIL CUP	1
14	SRT 12-702-06	RETAININGRING	1	32	SRT 36-504-02	FRONT PLATE	1	50	SRT 75-704-07	FRONT CAP	1
15	SRT 13-701-05	SCREW	2	33	SRT 37-504-01	REAR PLATE	1	51	SRT 77-608-03	REAR CAP	1
16	SRT 13-701-10	SCREW	1	34	SRT 38-505-01	CYLINDER	1	52	SRT 78-618-01	HANDLE	1
17	SRT 13-702-04	SCREW	2	35	SRT 39-701-04	NUT (RH)	2				
18	SRT 15-700-02	BALL BEARING	3	36	SRT 39-705-02	NUT (LH)	1				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.