




RT 9548 – IMPACT DRIVER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 9548 -01	AIR INLET	1	34	SRT 9548 -32	RUBBER RING	1
2	SRT 9548 -02	O - RING	1	35	SRT 9548 -33	SOCKET RETAINER	1
3	SRT 9548 -03	O - RING	1	36	SRT 9548 -34	LOCK RING	1
4	SRT 9548 -04	EXHAUST DEFLECTOR	1	37	SRT 9548 -35	CONNECTOR	1
5	SRT 9548 -05	SPRING	1	38	SRT 9548 -36	BUSHING	1
6	SRT 9548 -06	THROTTLE VALVE ASSEMBLY	1	39	SRT 9548 -37	BEARING	1
7	SRT 9548 -06-1	THROTTLE VALVE	1	40	SRT 9548 -38	RATCHET HOUSING ASSMEBLY	1
8	SRT 9548 -06-2	THROTTLE VALVE PIN	1	41	SRT 9548 -39	GREASE FITTING	1
9	SRT 9548 -07	O - RING	1	42	SRT 9548 -40	CRANK SHAFT	1
10	SRT 9548 -08	THROTTLE VALVE SEAT	1	43	SRT 9548 -41	DRIVE BUSHING	1
11	SRT 9548 -09	MOTOR HOUSING	1	44	SRT 9548 -42	RATCHET YOKE	1
12	SRT 9548 -10	TRIGGER	1	45	SRT 9548 -43	HOUSING COVER	1
13	SRT 9548 -11	SPRING PIN	1	46	SRT 9548 -44	RATCHET ANVIL ASSEMBLY	1
14	SRT 9548 -12	O - RING	1	47	SRT 9548 -45	STEEL BALL SPRING	1
15	SRT 9548 -13	BUSHING	1	48	SRT 9548 -46	STEEL BALL	1
16	SRT 9548 -14	VALVE STEM	1	49	SRT 9548 -47	REVERSE KNOB	1
17	SRT 9548 -15	HOUSING	1	50	SRT 9548 -48	SPRING	2
18	SRT 9548 -16	BEARING WASHER	1	51	SRT 9548 -49	PIN	2
19	SRT 9548 -17	BEARING	1	52	SRT 9548 -50	PAWL	2
20	SRT 9548 -18	REAR END PLATE	1	53	SRT 9548 -51	PIN	2
21	SRT 9548 -19	ROTOR	1	54	SRT 9548 -52	STEEL BALL SPRING	1
22	SRT 9548 -20	ROTOR BLADE	7	55	SRT 9548 -53	PIN	1
23	SRT 9548 -21	SPRING PIN	1	56	SRT 9548 -54	ANVIL UPPER WASHER	1
24	SRT 9548 -22	CYLINDER	1	57	SRT 9548 -55	SPRING	1
25	SRT 9548 -23	FRONT END PLATE	1	58	SRT 9548 -56	PIN	2
26	SRT 9548 -24	BEARING	1	59	SRT 9548 -57	REVERSE FIXING KNOB	1
27	SRT 9548 -25	SPACER	1	60	SRT 9548 -58	SCREW	1
28	SRT 9548 -26	HAMMER FRAME	1	61	SRT 9548 -59	FRICTION WASHER	1
29	SRT 9548 -27	HAMMER	1	62	SRT 9548 -60	THRUST WASHER	1
30	SRT 9548 -28	HAMMER PIN	2	63	SRT 9548 -61	RETAINER	1
31	SRT 9548 -29	STANDARD ANVIL	1	64	SRT 9548 -62	O - RING	1
32	SRT 9548 -30	HAMMER CASE BUSHING	1	65	BN 00TK	TUNE-UP KIT	
33	SRT 9548 -31	HAMMER CASE	1				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.