




RT 9610 – BELT SANDER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 9610-01	GRINDING BELT	1	28	SRT 9610-23	CAP	1
2	SRT 9610-1A	GRINDING BELT	1	29	SRT 9610-24	BALL BEARING	1
3	SRT 9610-1B	GRINDING BELT	1	30	SRT 9610-25	END PLATE	1
4	SRT 9610-02	IDLE PULLEY 10 SUB ASSY	1	31	SRT 9610-26	CYLINDER	1
5	SRT 9610-2A	IDLE PULLEY	1	32	SRT 9610-26A	PIN	1
6	SRT 9610-2B	BALL BEARING	2	33	SRT 9610-27	BLADE	5
7	SRT 9610-04	NEEDLE ROLLER	1	34	SRT 9610-28	ROTOR	1
8	SRT 9610-05	BRACKET	1	35	SRT 9610-29	THROTTLE LEVER	1
9	SRT 9610-06	TENSION BAR	1	36	SRT 9610-30	LEVER PIN	1
10	SRT 9610-07	SCREW	1	37	SRT 9610-31	VALVE BODY	1
11	SRT 9610-08	SCREW	1	38	SRT 9610-33	O - RING	1
12	SRT 9610-09	SPRING	1	39	SRT 9610-34	O - RING	1
13	SRT 9610-10	SPRING PIN	2	40	SRT 9610-35	VALVE STEM	1
14	SRT 9610-11	SPRING	1	41	SRT 9610-36	O - RING	1
15	SRT 9610-12	SHOE	1	42	SRT 9610-37	ALVE SPRING	1
16	SRT 9610-13	SCREW	1	43	SRT 9610-38	DEFRECTOR	1
17	SRT 9610-14	GUARD SUD ASSY	1	44	SRT 9610-39	AIR INLET	1
18	SRT 9610-14A	GUARD BUSHING	1	45	SRT 9610-40	TENSION BAR	1
19	SRT 9610-15	SCREW	1	46	SRT 9610-41	SPRING	1
20	SRT 9610-16	HEXAGON NUT	1	47	SRT 9610-42	LEVER PIN	1
21	SRT 9610-16A	WASHER	1	48	SRT 9610-43	LEVER PIN	1
22	SRT 9610-17	DRIVE PULLEY	1	49	SRT 9610-44	DUST COVER	1
23	SRT 9610-18	HOUSING	1	50	SRT 9610-45	HEXAGON WRENCH KEY	1
24	SRT 9610-19	BALL BEARING	1	51	SRT 9610-46	HEXAGON WRENCH KEY	1
25	SRT 9610-20	END PLATE	1	52	SRT 9610-47	O - RING	1
26	SRT 9610-21	SPACER	1	53	SRT 9610-48	O - RING	1
27	SRT 9610-22	SUNK KEY	1				

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.