




RT 601AQ - IMPACT SCREW DRIVER



SI.NO	PART NO	DESCRIPTION	QTY	SI.NO	PART NO	DESCRIPTION	QTY
1	SRT 601AQ- 01-102-03	ROTOR BLADE	6	21	SRT 601AQ- 31-703-01	HOOK	1
2	SRT 601AQ- 02-200-07	O - RING	1	22	SRT 601AQ- 35-706-08	ROTOR	1
3	SRT 601AQ- 03-300-02	PLASTIC BALL	2	23	SRT 601AQ- 36-503-03	FRONT PLATE	1
4	SRT 601AQ- 03-700-04	STEEL BALL	1	24	SRT 601AQ- 37-503-02	REAR PLATE	1
5	SRT 601AQ- 03-700-07	STELL BALL	1	25	SRT 601AQ- 38-503-01	CYLINDER	1
6	SRT 601AQ- 04-700-03	PIN	1	26	SRT 601AQ- 39-503-02	BOLT	1
7	SRT 601AQ- 04-701-04	PIN	1	27	SRT 601AQ- 40-701-02	HAMMER	2
8	SRT 601AQ- 04-702-04	PIN	1	28	SRT 601AQ- 41-703-01	HAMMER CASE	1
9	SRT 601AQ- 04-702-05	PIN	2	29	SRT 601AQ- 43-702-01	HAMMER CAM	1
10	SRT 601AQ- 06-701-10	SPRING	1	30	SRT 601AQ- 51-402-09	BUSHING	2
11	SRT 601AQ- 09-702-04	STOPPING WHEEL	1	31	SRT 601AQ- 51-501-02	BUSHING	1
12	SRT 601AQ- 10-701-01	STOPPING WHEEL	1	32	SRT 601AQ- 51-702-02	BUSHING	1
13	SRT 601AQ- 12-700-06	RETAINING RING	1	33	SRT 601AQ- 52-501-03	WASHER	1
14	SRT 601AQ- 13-702-01	SCREW	1	34	SRT 601AQ- 52-701-02	WASHER	1
15	SRT 601AQ- 15-701-07	BALL BEARING	1	35	SRT 601AQ- 52-701-17	WASHER	1
16	SRT 601AQ- 15-702-02	BALL BEARING	1	36	SRT 601AQ- 52-702-05	WASHER	1
17	SRT 601AQ- 17-704-01	SWITCH LEVER	1	37	SRT 601AQ- 54-701-02	O - RING	1
18	SRT 601AQ- 20-702-01	ROD	2	38	SRT 601AQ- 74-706-05	ANVIL	1
19	SRT 601AQ- 25-702-12	AIR INLET	1	39	SRT 601AQ- 75-604-01	FRONT CAP	1
20	SRT 601AQ- 26-501-02	MUFFLER	1	40	SRT 601AQ- 79-608-09	HANDLE	1

RAMSIVE TOOLS PVT.LTD.

S.F.No:412, Tex park Road, Nehru Nagar, SITRA, Coimbatore-641014.

Phone: 91-422-2905003 - Mobile: 9047023253.